PARTS CATALOGUE FOR

XL5010
XL5010NTP
XL5011
XL5011AV
XL5011NTC
XL5011NTP
XL5012
XL5012AV
XL5012NTP
XL5012NTP AV
XL5020
XL5020NTP
XL5021
XL5021AV
XL5021NTC
XL5021NTP
XL5022AV
XL5022NTP
XL5022NTP AV
XL5030
XL5030NTP
XL5031
XL5031AV
XL5031NTC
XL5031NTP
XL5032
XL5032AV
XL5032NTP
XL5032NTP AV
XL5050
XL5050NTC
XL5060
XL5060NTC
XL5070
XL5070NTC
XL5130
XL5232
XL5300
XL5340
XL5500
XL5500NTC AV
XL5500 SE
XL5600
XL5600NTC AV
XL5700
XL5700NTC AV
RS-15
RS-25
RS-35
RXL5130
RXL5232
RXL5340
PX100
PX100HC
RPX100
PX100NTC
PX110NTC
PX150
PX200
PX200HC
PX200NTC
PX220NTC
PX300
PX300HC
PX300NTC
PX330NTC

12.2003.
05.2004.

CONTENTS

(1) PRINCIPAL PARTS
(XL Series) 2

PRINCIPAL PARTS
(PX Series) 6

(2) UPPER SHAFT / NEEDLE BAR / THREAD TENSION /
PRESSER MECHANISM 10

(3) HORIZONTAL FEED / VERTICAL FEED MECHANISM 12

(4) FEED ADJUSTMENT MECHANISM 14

(5) ROTARY HOOK DRIVE /
ROTARY HOOK MECHANISM 16

(6) ZIGZAG / BH MECHANISM 18

(7) PATTERN SELECTION MECHANISM
without BH CONNECTING LINK ASSY 20

PATTERN SELECTION MECHANISM
with BH CONNECTING LINK ASSY 22

(8) BOBBIN WINDER / THREAD GUIDE / LAMP MECHANISM 24

(9) MOTOR UNIT 26

(10) ATTACHMENTS / PACKING MATERIALS /
PRINTED MATTERS 30

(1) PRINCIPAL PARTS (XL Series)

No.	CODE.	NAME	REMARKS
1	XA5721021	FRONT COVER (XL5300)	
	XA5721024	FRONT COVER (XL5130, RXL5130)	
	XA5721025	FRONT COVER (XL5232, RXL5232)	
	XA5721026	FRONT COVER (XL5340, RXL5340)	
	XA6009021	FRONT COVER (XL501*)	
	XC7329021	FRONT COVER (XL5500, XL5500NTC AV)	
	XC7329022	FRONT COVER (XL5600*)	
	XC7329023	FRONT COVER (XL5700*)	
	XC7329024	FRONT COVER (XL5500SE)	
	XC7329025	FRONT COVER (RS15)	
	XC7329026	FRONT COVER (RS25)	
	XC7329027	FRONT COVER (RS35)	
	XC7431021	FRONT COVER (XL5050*, XL5060*, XL5070*)	
2	XA5739021	DECORATION PLATE (XL5300)	
	XA5739027	DECORATION PLATE (XL5130, RXL5130)	
	XA5739028	DECORATION PLATE (XL5232, RXL5232)	
	XA5739029	DECORATION PLATE (XL5340, RXL5340)	
	XC7331021	DECORATION PLATE (XL5500, XL5500NTC AV)	
	XC7331022	DECORATION PLATE (XL5600*)	
	XC7331023	DECORATION PLATE (XL5700*)	
	XC7331025	DECORATION PLATE (XL5060*)	
	XC7331027	DECORATION PLATE (XL5050*)	
	XC7331028	DECORATION PLATE (XL5070*)	
	XC7331029	DECORATION PLATE (XL5500SE)	
	XC7331031	DECORATION PLATE (RS-15)	
	XC7331032	DECORATION PLATE (RS-25)	
	XC7331033	DECORATION PLATE (RS-35)	
	XA6010021	DISPLAY SHEET (XL5030*)	
	XA6010022	DISPLAY SHEET (XL5020*)	
	XA6010023	DISPLAY SHEET (XL5010*)	
	XA6010027	DISPLAY SHEET (XL5011*)	
	XA6010028	DISPLAY SHEET (XL5021*)	
	XA6010029	DISPLAY SHEET (XL5031*)	
	XA6010031	DISPLAY SHEET (XL5012*)	
	XA6010032	DISPLAY SHEET (XL5032*)	
	XA6010033	DISPLAY SHEET (XL5022*)	
3	XA4657021	CUSHION	
	XA4657051	CUSHION (XL5130, XL5232: U.S.A.), (XL5340) (RXL5130), (RXL5232), (RXL5340)	
4	XA5732021	BOTTOM HOLD PLATE	
5	XA3337022	TAPTITE CUP P M4X20	

No.	CODE.	NAME	REMARKS
6	XA5748021	MYLAR STICKER 4STEP (XL5130, XL5500: CANADA)	
	XA5749021	MYLAR STICKER 1STEP (XL5232, XL5600, XL5700:CANADA)	
7	XA6583022	DROP MARK (XL5500, XL5600, XL5700: GER, U.K, FRA), (XL5500SE), (XL5500NTC AV), (XL5600NTC AV), (XL5700NTC AV), (RS15), (RS25)	
8	XC8623021	QUICK SYSTEM STICKER (RS-35)	
9	053400806	SCREW, PAN (T WASHER) M4X8	
10	XA5723121	REAR COVER	
	XC7333021	REAR COVER (XL5050*, XL5060*, XL5070*, XL5500*, XL5600*, XL5700*, RS15, RS25, RS35)	
11	XA6106021	THREAD GUIDE ASSY	
12	0A5301006	SCREW, PAN (S/P WASHER) M3X10	
13	052301606	SCREW, PAN (S/P WASHER) M3X16	
14	021300106	NUT, 1 M3	
15	188058121	SPOOL PIN	
16	XA4441021	SPOOL PIN STAND	
17	XA0628021	SPOOL PIN SPRING	
18	X59864221	BOBBIN PRESSER	040152
19	XA5724021	HINGE DOOR ASSY (XL5340)	
	XA5724022	HINGE DOOR ASSY (XL5700*, RS35)	
20	XA5963021	HINGE DOOR	
	XA5963022	HINGED DOOR (XL5050*, XL5060*, XL5070*, XL5500*, XL5600*, RS15, RS25)	
21	X53638121	SPRING	
22	X53625121	UPPER COVER THREAD GUIDE	
23	XA5726121	HANDLE	
	XA5726122	HANDLE (XL5050*, XL5060*, XL5070*, XL5500*, XL5600*, XL5700*, RS15, RS25, RS35)	
24	XA8476020	HANDLE HOLDER XR	
25	XA8477020	HANDLE HOLDER XL	
26	XA3337022	TAPTITE, CUP P M4X20	
27	XA5728121	FACE PLATE	
	XC7336021	FACE PLATE (XL5050*, XL5060*, XL5070*, XL5500*, RS15, XL5600*, RS25, XL5700*, RS35)	
28	0A0211850	SPRING PIN	

(1) PRINCIPAL PARTS (XL Series)



(1) PRINCIPAL PARTS (XL Series)

No.	CODE.	NAME	REMARKS
29	X80321001	NT LOWER THREAD CUTTER (RXL5130, RXL5232, RXL5340)	
	X80321021	NT LOWER THREAD CUTTER	
30	136681021	TAPTITE, BIND B M3X8 (XL5340, XL5700*, RS35)	
31	138384021	RETAINING RING,CS5	
	138384051	RETAINING RING,CS5 (RXL5130, RXL5232, RXL5340)	
32	X51895021	FACE PLATE BUSH	
	X51895051	FACE PLATE BUSH (RXL5130, RXL5232, RXL5340)	
33	XA4468021	REAR COVER REFLECTOR	
34	060401416	SCREW, BIND M4X14	
35	XA5730021	ACCESSORY TABLE	
	XA5730024	ACCESSORY TABLE (XL5050*, XL5060*, XL5070*, XL5500*, XL5600*, XL5700*, RS15, RS25, RS35)	
36	XA5731221	ACCESSORY TABLE COVER	
	XA5731222	ACCESSORY TABLE COVER (XL5050*, XL5060*, XL5070*, XL5500*, XL5600*, XL5700*, RS15, RS25, RS35)	
37	XA4569020	BASE PLATE	
38	XA4687021	ADJUSTING SCREW ASSY	
39	XA1805021	BASE RUBBER A	
40	XC0425021	MACHINE COVER ASSY (XL5020: KOREA)	
41	125440050	CASE FELT (XL5020: KOREA)	
42	XZ0016050	CASE FELT TOP (XL5020: KOREA)	
43	X60678051	BAG, 700X630H (XL5020: KOREA)	
44	XA3028021	DECORATION PLATE (XL5020: KOREA)	
45	060400816	SCREW, BIND M4X8	
46	XA6661021	PILE	
	XA6661051	PILE (RXL5130, RXL5232, RXL5340)	
47	XC4167021	CAUTION STICKER (KOREA)	
48	138172021	SCREW,PAN (S/P WASHER) M4X10	
	138172051	SCREW,PAN (S/P WASHER) M4X10 (RXL5130, RXL5232, RXL5340, XL5500SE)	
49	XA2107221	LABEL (XL5500, XL5700: U.S.A., CAN, CHILE) (XL5232), (XL5600: U.S.A., CAN), (XL5340), (XL5300), (XL5130)	
	XA2107251	LABEL (RXL5130, RXL5232: U.S.A.)	
50	125782021	SEW-LIGHT RATING STICKER (XL5500, XL5600, XL5700: U.S.A., CAN) (XL5130), (XL5232), (XL5300), (XL5340)	
	125782051	SEW-LIGHT RATING STICKER (RXL5130, RXL5232: U.S.A.)	
51	X56455021	HINGE DOOR LABEL (XL501*, XL5050*, XL502*, XL5060*, XL503*, XL5070*: U.K.), (XL5130), (XL5232), (XL5340), (XL5500*, XL5600*, XL5700*: U.S.A., CAN, U.K.)	
	X56455051	HINGE DOOR LABEL (RXL5130, RXL5232: U.S.A.)	
52	XC3372021	UPPER THREADING LABEL (XL501*, XL502*, XL503*: U.K.)	
	XC6750021	UPPER THREADING LABEL (XL5050*, XL5060*, XL5070*, XL5500*, XL5600*, XL5700*: U.K.)	

(1) PRINCIPAL PARTS (XL Series)



(1) PRINCIPAL PARTS (PX Series)

No.	CODE.	NAME	REMARKS
1	XA6356021	FRONT COVER (PX200, PX200NTC, PX200HC, PX220NTC, PX300, PX300HC, PX300NTC, PX330NTC)	
	XA6393021	FRONT COVER (PX100, PX100HC, PX100NTC, PX110NTC, PX150)	
2	XA6357021	PANEL DECORATION PLATE (PX300)	
	XA6357023	PANEL DECORATION PLATE (PX200, except PX200: U.S.A.)	
	XA6357024	PANEL DECORATION PLATE (PX100)	
	XA6357026	PANEL DECORATION PLATE (PX200: U.S.A.)	
	XA6357031	PANEL DECORATION PLATE (PX100NTC)	
	XA6357032	PANEL DECORATION PLATE (PX200NTC)	
	XA6357033	PANEL DECORATION PLATE (PX300NTC)	
	XA6357034	PANEL DECORATION PLATE (PX330NTC)	
	XA6357035	PANEL DECORATION PLATE (PX150)	
	XA6357036	PANEL DECORATION PLATE (PX110NTC)	
	XA6357037	PANEL DECORATION PLATE (PX220NTC)	
3	XA6358021	F PATTERN INDICATOR PLATE	
4	XA5732021	BOTTOM HOLD PLATE	
5	XA3337022	TAPTITE CUP P M4X20	
6	XA6583021	DROP MARK	
7	XA6359021	PATTERN DECORATION PLATE (PX300)	
	XA6359023	PATTERN DECORATION PLATE (PX300: ARGENTINE, CHILE, MEXICO)	
	XA6359025	PATTERN DECORATION PLATE (PX300NTC, PX330NTC)	
	XA6392021	PATTERN DECORATION PLATE (PX200)	
	XA6392022	PATTERN DECORATION PLATE (PX200: U.S.A.)	
	XA6392023	PATTERN DECORATION PLATE (PX200: ARGENTINE, CHILE, MEXICO)	
	XA6392025	PATTERN DECORATION PLATE (PX200NTC, PX220NTC)	
	XA6394021	PATTERN DECORATION PLATE	
	XA6394023	PATTERN DECORATION PLATE (PX100: ARGENTINE, CHILE, MEXICO)	
	XA6394025	PATTERN DECORATION PLATE (PX100NTC, PX110NTC, PX150)	
8	XA6360021	PATTERN DISPLAY RACK	
9	XA6361021	DISPLAY PLATE	
10	XA6361022	DISPLAY PLATE	
11	XA6362020	SPRING	
12	XA6363021	DISPLAY REAR PLATE	
13	146200051	RETAINING RING,CS4	
14	053400806	SCREW,PAN (T WASHER) M4X8	
15	XA5723121	REAR COVER	
16	XA6106021	THREAD GUIDE ASSY	040161
17	0A5301006	SCREW,PAN (S/P WASHER) M3X10	
18	188058121	SPOOL PIN	
19	XA4441021	SPOOL PIN STAND	
20	XA0628021	SPOOL PIN SPRING	
21	X59864221	BOBBIN PRESSER	040152
22	052301606	SCREW,PAN (S/P WASHER) M3X16	
23	021300106	NUT, 1 M3	
24	XA5724021	HINGE DOOR ASSY	
25	XA5963021	HINGE DOOR	
26	X53638121	SPRING	
27	X53625121	UPPER COVER THREAD GUIDE	
28	XA5726121	HANDLE	
29	XA8476020	HANDLE HOLDER XR	
30	XA8477020	HANDLE HOLDER XL	
31	XA3337022	TAPTITE, CUP P M4X20	
32	XA6365121	FACE PLATE	
33	X80321001	NT LOWER THREAD CUTTER (RPX100)	
	X80321021	NT LOWER THREAD CUTTER	
34	136681021	TAPTITE, BIND B M3X8	
35	138384021	RETAINING RING,CS5	
	138384051	RETAINING RING,CS5 (RPX100)	
36	XA4468021	REAR COVER REFLECTOR	
37	X51895021	FACE PLATE BUSH	
	X51895051	FACE PLATE BUSH (RPX100)	
38	X52654001	PILE 19X6X6	
39	060401416	SCREW, BIND M4X14	
40	XA5730022	ACCESSORY TABLE	
41	XA5731221	ACCESSORY TABLE COVER	
42	XA4569020	BASE PLATE	
43	XA4687021	ADJUSTING SCREW ASSY	
44	XA1805021	BASE RUBBER A	

(1) PRINCIPAL PARTS (PX Series)



(1) PRINCIPAL PARTS (PX Series)

No.	CODE.	NAME	REMARKS
45	XC0425021	MACHINE COVER ASSEMBLY (PX100HC), (PX100: KOREA) (PX200HC), (PX200: KOREA, IRAQ) (PX300HC), (PX300: IRAQ)	
46	125440050	CASE FELT (PX100HC), (PX100: KOREA) (PX200HC), (PX200: KOREA, IRAQ) (PX300HC), (PX300: IRAQ)	
47	XZ0016050	CASE FELT TOP (PX100HC), (PX100: KOREA) (PX200HC), (PX200: KOREA, IRAQ) (PX300HC), (PX300: IRAQ)	
48	X60678051	BAG, 700X630H (PX100HC), (PX100: KOREA) (PX200HC), (PX200: KOREA, IRAQ) (PX300HC), (PX300: IRAQ)	
49	XA3028021	DECORATION PLATE (PX100HC), (PX100: KOREA) (PX200HC), (PX200: KOREA, IRAQ) (PX300HC), (PX300: IRAQ)	
50	060400816	SCREW, BIND M4X8	
51	138172021	SCREW,PAN (S/P WASHER) M4X10	
	138172051	SCREW,PAN (S/P WASHER) M4X10 (RPX100, PX220NTC)	
52	XA2107221	LABEL (PX100, PX200, PX300: U.S.A.)	
53	X56455021	HINGE DOOR LABEL (PX100, PX200, PX300: U.S.A.)	
54	125782021	SEW-LIGHT RATING STICKER (PX100, PX200, PX300: U.S.A.)	
55	XC4167021	CAUTION STICKER (KOREA)	

(1) PRINCIPAL PARTS (PX Series)



(2) UPPER SHAFT / NEEDLE BAR / THREAD TENSION / PRESSER MECHANISM

No.	CODE.	NAME	REMARKS
		UPPER SHAFT MECHANISM	
1	XA7211321	UPPER SHAFT ASSEMBLY	
2	X52478021	BUSHING PRESSER	
3	X57908021	TAPTITE, BIND S M4X10	
4	XA8378021	PULLEY	
	XA8378022	PULLEY (XL5050*, XL5060*, XL5070*, XL5500* XL5600*, XL5700*, RS15, RS25, RS35)	
		NEDDLE BAR MECHANISM	
5	XA2358121	NEEDLE BAR	
6	XZ0005020	NEEDLE BAR THREAD GUIDE	
7	012400432	SET SCREW, SOCKET (FT) M4X4	
8	XZ0001121	NEEDLE CLAMP	
9	XA5718121	NEEDLE CLAMP PIN	040212
10	XZ0002021	NEEDLE CLAMP SCREW	
11	XA8379021	NEEDLE BAR SUPPORTER ASSY	
12	XA3952220	NEEDLE BAR SUPPORTER	
13	XA1289121	NEEDLE BAR CRANK ROD ASSY	
14	XA3477021	NEEDLE BAR SUPPORTER STUD	
15	X54369021	SPRING	
16	X56851021	LOCK NUT	
17	XA8380021	NEEDLE BAR SUPPORTER GUIDE	
18	X59115121	NEEDLE BAR CRANK	
19	132051022	SCREW, FLAT SM3.57-40X7 L	
20	XA3954021	ZIGZAG NEEDLE PLATE	
21	X50487051	SCREW M4	
22	X57908021	TAPTITE, BIND S M4X10 (XL5***NTP, NTC, NTP AV, NTC AV, SE, XL5130,RXL5130: U.S.A., XL5232, RXL5232, XL5500,XL5600: U.S.A., CANADA, CHILE, XL5340, RXL5340, XL5700, RS35)	
23	XA2367020	NEEDLE THREADER SET COLLAR	
24	XA0430021	NEEDLE THREADER SET PLATE	
25	004260405	SCREW, FLAT M2.6X4	
26	XA5535021	NEEDLE THREADER SUPPORTER ASSY	
27	XA0445151	THREADER HOOK ASSEMBLY	
28	037200516	TAPPING SCREW, PAN V M2X5	040207
29	060400616	SCREW, BIND M4X6	
		THREAD TENSION MECHANISM	
30	XA4747021	THREAD TAKE-UP LEVER ASSY	
31	XA4585021	THREAD TAKE-UP LEVER SHAFT	
32	048050346	RETAINING RING, E5	
33	X57913021	TAPTITE, BIND S M4X16	
34	X50532021	PRESSER PLATE	

No.	CODE.	NAME	REMARKS
		PRESSER MECHANISM	
35	XA2402050	PRESSER BAR	
	XA2402020	PRESSER BAR (XL5050NTC), (XL5060NTC), (XL5070NTC), (XL5500: U.S.A., CAN, CHILE), (XL5500SE), (XL5500NTC AV), (XL5600: U.S.A., CAN), (XL5600NTC AV), (XL5700), (XL5700NTC AV)	
	128437020	PRESSER BAR (XL5010), (XL5011), (XL5011AV), (XL5012), (XL5020), (XL5021), (XL5012AV), (XL5022AV), (XL5021AV), (XL5030), (XL5031), (XL5031AV), (XL5032), (XL5032AV), (PX100), (PX200), (XL5050), (XL5060), (XL5070), (RS15), (RS25), (XL5500, XL5600: GER, U.K., FRA)	040158
36	X55770021	PRESSER BAR SPRING	
37	XA3955121	PRESSER BAR BRACKET	
38	X52760021	SET SCREW,PAN M6X12	
	X52760051	SET SCREW,PAN M6X12 (RXL5130, RXL5232, RXL5340, RPX100)	
39	XA2511121	PRESSER FOOT LIFTER	
40	XA0977120	PRESSER FOOT LIFTER STUD	
41	138135122	ZIGZAG PRESSER FOOT	
	138135152	ZIGZAG PRESSER FOOT (RXL5130, RXL5232, RXL5340, RPX100)	
42	138134021	PRESSER FOOT HOLDER	
	138134051	PRESSER FOOT HOLDER (RXL5130, RXL5232, RXL5340, RPX100)	
43	132730122	TIGHTENING SCREW 3.57	
44	XA5796021	TENSION RELEASER C	
45	120454021	RETAINING RING, CS3	
	120454051	RETAINING RING, CS3 (RXL5130, RXL5232, RXL5340, RPX100)	
46	XA5797021	SPRING	
47	025030236	WASHER, PLAIN M3	
48	XA5737021	BH LEVER SET PLATE	
49	X57908021	TAPTITE, BIND S M4X10	

(2) UPPER SHAFT / NEEDLE BAR / THREAD TENSION / PRESSER MECHANISM



XL5***NTP, NTC, NTP AV, NTC AV, SE, XL5130,RXL5130: U.S.A., XL5232, RXL5232, XL5500,XL5600: U.S.A., CANADA, CHILE, XL5340, RXL5340, XL5700, RS35

(3) HORIZONTAL FEED / VERTICAL FEED MECHANISM

No.	CODE.	NAME	REMARKS
		HORIZONTAL FEED MECHANISM	
1	XA0978021	FEED CONNECTING ROD ASSY	
2	XA0980021	SPRING	
3	XA3958020	HORIZONTAL FEED SHAFT	
4	XA0983121	HORIZONTAL FEED ARM ASSY	
5	021400205	NUT, 2 M4	
6	060401416	SCREW, BIND M4X14	
7	XA0987021	HORIZONTAL FEED PLATE	
8	XA0988021	FEED STAND SHAFT	
9	XA3960021	FEED STAND	
10	048030346	RETAINING RING, E3	
11	146200051	RETAINING RING, CS4	
12	XA4430021	FEED DOG	
13	XA3474021	DUST PROTECT PLATE	
14	060300416	SCREW, BIND M3X4	
15	060400816	SCREW, BIND M4X8	
16	X53330020	WASHER	
17	XA1082021	TAPER POINT STUD R (XL5050*, XL5060*, XL5070*, XL5500*, XL5600*, XL5700*, RS15, RS25, RS35)	
	XA1082051	TAPER POINT STUD R	
18	XZ0074021	TAPTITE, CUP S4X16	
19	XA0991021	SPRING	
20	X55472021	TAPER POINT STUD L ASSY	
21	X56613021	SPRING	
22	XA0649021	TAPTITE, CUP S4X14	
23	XA3962021	SS CONNECTING ROD	
24	X56960021	NUT 4	
25	XA3082121	SS CHANGE LEVER SUB ASSY	
26	XA3085021	SS FEED LEVER ASSY	
27	XA3087021	SS FEED LEVER SHAFT	
28	048050346	RETAINING RING, E5	
29	XA3080121	SS ADJUSTING SHAFT	
30	048040346	RETAINING RING, E4	
31	XA3088021	SS FEED ROD	
32	048030346	RETAINING RING, E3	
33	048050346	RETAINING RING, E5	
34	XA4042120	FEED STAND SUPPORT	
35	XA4692021	SPRING	
36	025040133	WASHER, PLAIN S4	

No.	CODE.	NAME	REMARKS
		VERTICAL FEED MECHANISM	
37	XA3480021	VERTICAL FEED ARM (XL501*), (XL5050*), (XL502*), (XL5060*), (XL503*), (XL5070*), (XL5130), (RXL5130), (XL5232), (RXL5232), (XL5340), (RXL5340), (XL5500, XL5700: U.S.A., CAN, CHILE), (XL5300), (XL5600: U.S.A., CAN)	
38	XA3481021	VERTICAL FEED ADJUSTER	
39	XA1504021	VERTICAL FEED SHAFT ARM (XL5500, XL5600, XL5700: GER, U.K., FRA) (XL5500SE), (XL5500NTC AV), (XL5600NTC AV), (XL5700NTC AV), (RS15), (RS25), (RS35), (PX100), (PX100HC), (PX100NTC), (PX110NTC), (RPX100), (PX150), (PX200), (PX200HC), (PX200NTC), (PX220NTC) (PX300), (PX300HC), (PX300NTC), (PX330NTC)	
40	XA1660021	VERTICAL ADJUSTING	
41	X50559020	ZIGZAG ADJUSTING NUT	
	X50559050	ZIGZAG ADJUSTING NUT (RXL5130, RXL5232, RXL5340)	
42	062300806	SCREW, PAN M3X8	
43	060400516	SCREW, BIND M4X5	
44	XA0995121	VERTICAL FEED SHAFT	
45	048060346	RETAINING RING, E6	
46	048030346	RETAINING RING, E3	
47	XA1659021	NOTCH SPRING	
48	X57908021	TAPTITE, BIND S M4X10	
49	XA2338021	DROP STOPPER	
50	052401406	SCREW, PAN (S/P WASHER) M4X14	
51	XA1505021	DROP LEVER	
	XA1505051	DROP LEVER (RPX100), (XL5700: GER, U.K, FRA), (RS35)	

(3) HORIZONTAL FEED / VERTICAL FEED MECHANISM





XL501*, XL5050*, XL502*, XL5060*, XL503*, XL5070*,
XL5130, RXL5130, XL5500(U.S.A., CAN, CHILE),
XL5232, RXL5232, XL5600(U.S.A., CAN), XL5340,
XL5300, RXL5340, XL5700(U.S.A., CAN, CHILE)



XL5500(GER, U.K., FRA),
XL5500SE, XL5500NTC AV,
XL5600(GER, U.K., FRA),
XL5600NTC AV,
XL5700(GER, U.K., FRA)
XL5700NTC AV, RS15, RS25, RS35,
PX100, PX100HC, PX100NTC, RPX100,
PX110NTC, PX150, PX200, PX200HC, PX200NTC, PX220NTC,
PX300, PX300HC, PX300NTC, PX330NTC

(4) FEED ADJUSTMENT MECHANISM

No.	CODE.	NAME	REMARKS
1	XA0030021	FEED SQUARE BLOCK	
2	XA3089051	FEED REGULATOR ASSY	
	XA3089021	FEED REGULATOR ASSY (XL5050, XL5050NTC, XL5060, XL5060NTC, XL5070, XL5070NTC, XL5500, XL5500SE, XL5500NTC AV, RS15, XL5600, XL5600NTC AV, RS25, XL5700, XL5700NTC AV, RS35)	
3	X53330020	WASHER	
4	XA4534021	STOP PLATE L	
5	X57913021	TAPTITE, BIND S M4X16	
6	XA0998021	SPRING	
7	XA3092021	FEED REGULATOR PLATE ASSY	
8	XA4343021	REVERSE SEWING LEVER ASSY	
	XA6366021	REVERSE SEWING LEVER (PX Series)	
9	XA4532121	REVERSE SEWING LEVER PLATE A	
10	XA4675021	SPRING	
11	XA1004120	REVERSE SEWING SHAFT	
12	XA6582021	REVERSE BUTTON HOLDER	
13	XA5733021	FEED REGULATING LEVER KNOB	
	XC7338021	FEED REGULATING LEVER KNOB (XL5050, XL5050NTC, XL5060, XL5060NTC, XL5070, XL5070NTC, XL5500, XL5500SE, XL5500NTC AV, RS15, XL5600, XL5600NTC AV, RS25, XL5700, XL5700NTC AV, RS35)	
14	XA6369021	REVERSE SEWING BUTTON (PX Series)	
15	XA6015021	FEED REGULATOR CAM	
16	048040346	RETAINING RING, E4	
17	048050346	RETAINING RING, E5	
18	XA5734021	MANUAL DIAL	
	XC7339121	MANUAL DIAL (XL5050, XL5050NTC, XL5060, XL5060NTC, XL5070, XL5070NTC, XL5500, XL5500SE, XL5500NTC AV, RS15, XL5600, XL5600NTC AV, RS25, XL5700, XL5700NTC AV, RS35)	
19	XA6370021	FEED DIAL (PX Series)	
	XA6370022	FEED DIAL (PX300NTC)	
	XA6370023	FEED DIAL (PX100NTC)	
	XA6370024	FEED DIAL (PX200NTC)	
20	XA5735021	DIAL SHEET (XL5340, RXL5340, XL5300, XL5030, XL5030NTP)	
	XA5735024	DIAL SHEET (XL5020, XL5020NTP, XL5232, RXL5232)	
	XA5735025	DIAL SHEET (XL5010, XL5010NTP, XL5130, RXL5130)	
	XA5735028	DIAL SHEET (XL5011, XL5011AV, XL5011NTP, XL5011NTC)	
	XA5735029	DIAL SHEET (XL5021, XL5021AV, XL5021NTP, XL5021NTC)	
	XA5735030	DIAL SHEET (XL5031, XL5031AV, XL5031NTP, XL5031NTC)	
	XA5735032	DIAL SHEET (XL5012, XL5012AV, XL5012NTP, XL5012NTP AV)	
	XA5735033	DIAL SHEET (XL5032, XL5032AV, XL5032NTP, XL5032NTP AV)	
	XA5735034	DIAL SHEET (XL5022AV, XL5022NTP, XL5022NTP AV)	
	XC7370021	DIAL SHEET (XL5500, XL5500NTC AV)	
	XC7370023	DIAL SHEET (XL5600, XL5600NTC AV)	
	XC7370025	DIAL SHEET (XL5700, XL5700NTC AV)	
	XC7370029	DIAL SHEET (XL5050, XL5050NTC)	
	XC7370028	DIAL SHEET (XL5060, XL5060NTC)	
	XC7370030	DIAL SHEET (XL5070, XL5070NTC)	
	XC7370031	DIAL SHEET (XL5500SE)	
	XC7370034	DIAL SHEET (RS-15)	
	XC7370036	DIAL SHEET (RS-25)	
	XC7370038	DIAL SHEET (RS-35)	
21	XA3099021	SPRING	

(4) FEED ADJUSTMENT MECHANISM



(5) ROTARY HOOK DRIVE / ROTARY HOOK MECHANISM

No.	CODE.	NAME	REMARKS
		ROTARY HOOK DRIVE MECHANISM	
1	XA4693121	CAM DRIVE CONNECTING ROD A	
2	XA1012221	CAM DRIVE CONNECTING ROD B	
3	XA3969021	CONNECTING ROD C ASSY	
4	XA1017120	RACK	
5	052300606	SCREW, PAN (S/P WASHER) M3X6	
6	048040346	RETAINING RING, E4	
7	060400816	SCREW, BIND M4X8	
8	131976020	WASHER, THRUST	
9	XA1019021	RACK PLATE SPRING	
10	XA6909021	TOOTHED WASHER	
	XA6909051	TOOTHED WASHER (RXL5130, RXL5232, RXL5340, RPX100)	
11	X52077121	COLLAR	
12	014400432	SET SCREW, SOCKET (CP) M4X4	
13	X53330020	WASHER	
14	XA8290021	TAPTITE, BIND S M4X8	
	XA8290051	TAPTITE, BIND S M4X8 (RXL5130, RXL5232, RXL5340, RPX100)	
15	X50559020	ZIGZAG ADJUSTING NUT	
	X50559050	ZIGZAG ADJUSTING NUT (RXL5130, RXL5232, RXL5340, RPX100)	
16	062301006	SCREW, PAN M3X10	

No.	CODE.	NAME	REMARKS
		ROTARY HOOK MECHANISM	
17	XA1317051	SHUTTLE RACE ASSEMBLY	
	XA1317021	SHUTTLE RACE ASSEMBLY (XL5070, XL5070NTC, XL5700, XL5700NTC AV, RS35)	
	XA1317022	SHUTTLE RACE ASSEMBLY (XL5050, XL5050NTC, XL5060, XL5060NTC, XL5500, XL5500SE, XL5500NTC AV, XL5600, XL5600NTC AV, RS15, RS25)	
18	128581053	SHUTTLE HOOK	
	128581021	SHUTTLE HOOK (XL5070, XL5070NTC, XL5700, XL5700NTC AV, RS35)	
	128581022	SHUTTLE HOOK (XL5050, XL5050NTC, XL5060, XL5060NTC, XL5500, XL5500SE, XL5500NTC AV, XL5600, XL5600NTC AV, RS15, RS25)	
19	XA1021051	SHUTTLE DRIVE ASSY	
	XA1021052	SHUTTLE DRIVE ASSY (PX300, PX300NTC, PX330NTC, PX300HC)	
	XA1021021	SHUTTLE DRIVE ASSY (XL5050, XL5050NTC, XL5060, XL5060NTC, XL5070, XL5070NTC, XL5500, XL5500SE, XL5500NTC AV, XL5600, XL5600NTC AV, XL5700, XL5700NTC AV, RS15, RS25, RS35)	
20	XA1025021	DRIVER SHAFT GEAR	
21	132434020	WASHER	
22	128582023	BOBBIN CASE ASSEMBLY	
23	X52800120	BOBBIN	
24	014400632	SET SCREW, SOCKET (CP) M4X6	
25	X57313121	RACK STOPPER	
26	XA5702021	RACK STOPPER A	
27	X57908021	TAPTITE, BIND S M4X10	

(5) ROTARY HOOK DRIVE / ROTARY HOOK MECHANISM



(6) ZIGZAG / BH MECHANISM

No.	CODE.	NAME	REMARKS
		ZIGZAG MECHANISM	
1	XA4466021	Z CONNECTING ROD (XL501*, XL5050*, XL502*, XL5060*, XL503* XL5070*)	
	XA3971021	Z CONNECTING ROD (XL5130, XL5500*, XL5600*, XL5700*, XL5232 XL5340, XL5300, RS15, RS25, RS35, PX100* PX110NTC, RPX100, PX200*, PX220NTC, PX300*, PX330NTC)	
	XA3971051	Z CONNECTING ROD (RXL5130, RXL5232, RXL5340, RPX100)	
2	XA8474021	UPSET 4X12DB	
	XA8474051	UPSET 4X12DB (RXL5130, RXL5232, RXL5340, RPX100)	
3	XZ0024021	ZIGZAG CONNECTING ROD SPRING	
	XA3143021	ZIGZAG CONNECTING ROD SPRING (XL5130, XL5232, RXL5130, RXL5232, XL5300, XL5340, RXL5340, XL5500, XL5500SE, XL5500NTC AV, XL5600, XL5600NTC AV, XL5700, XL5700NTC AV, RS15, RS25, RS35, PX100*, PX110NTC, RPX100, PX200*, PX220NTC, PX300*, PX330NTC)	
4	X50559020	ZIGZAG ADJUSTING NUT	
	X50559050	ZIGZAG ADJUSTING NUT (RXL5130, RXL5232, RXL5340, RPX100)	
5	062301006	SCREW, PAN M3X10	
		BH MECHANISM	
		(XL502*, 5060*, XL503*, XL5070*, XL5232 RXL5322, XL5600*, XL5340, RXL5340, XL5300, XL5700*, RS15, RS25, RS35, PX200*, PX220NTC, PX300*, PX330NTC)	
6	XZ0021021	BH CHANGE ARM ASSY	
7	XA3972021	BH NOTCH SPRING	
8	136997021	BH SPRING	
9	060400816	SCREW, BIND M4X8	
10	XA5812021	BH LEVER SET PLATE ASSY	
11	XA3975151	BH LEVER HOLDER ASSEMBLY	
12	XA3978021	BH CHANGE SHAFT	
13	048025346	RETAINING RING, E2.5	
14	XA3979021	BH HOLDER ASSY	
15	X57908021	TAPTITE, BIND S M4X10	

(6) ZIGZAG / BH MECHANISM



(7) PATTERN SELECTION MECHANISM without BH CONNECTING LINK ASSY

No.	CODE.	NAME	REMARKS
1	XA6004021	PATTERN SELECTING UNIT ASSY (XL5130, RXL5130)	
	XA6013021	PATTERN SELECTING UNIT ASSY (XL5010, XL5010NTP, XL5011, XL5011AV, XL5011NTC, XL5011NTP, XL5012, XL5012AV, XL5012NTP, XL5012NTP AV, XL5050, XL5050NTC)	
	XC7341021	PATTERN SELECTING UNIT ASSY (XL5500, XL5500SE, XL5500NTC AV, RS15)	
	XA9837021	PATTERN SELECTING UNIT ASSY (PX100, PX100NTC, PX100HC, PX150, PX110NTC, RPX100)	
2	X57908021	TAPTITE, BIND S M4X10	
	X57908051	TAPTITE, BIND S M4X10 (XL5050, XL5050NTC)	
3	XA5736021	PATTERN SELECTION DIAL	
	XA6371021	PATTERN SELECTION DIAL (PX100, PX100HC, RPX100, PX110NTC)	
	XA6371023	PATTERN SELECTION DIAL (PX100NTC)	
	XC7343021	PATTERN SELECTION DIAL (XL5050, XL5050NTC, XL5500, XL5500SE, XL5500NTC AV, RS15)	
4	XA6372021	PATTERN DECORATION GEAR 1 (PX100, PX100HC, PX100NTC, PX110NTC. RPX100)	
5	XA5734021	MANUAL DIAL (XL5130, RXL5130)	
	XC7339121	MANUAL DIAL (XL5500, XL5500SE, XL5500NTC AV, RS15)	
6	XA6373021	ZIGZAG DIAL (PX100, PX100NTC, PX110NTC, RPX100)	
	XA6373023	ZIGZAG DIAL (PX100NTC)	
7	XA6003025	DIAL SHEET (XL5010, XL5010NTP)	
	XA6003030	DIAL SHEET (XL5011, XL5011AV, XL5011NTP, XL5011NTC)	
	XA6003034	DIAL SHEET (XL5130, RXL5130)	
	XA6003037	DIAL SHEET (XL5012, XL5012AV, XL5012NTP, XL5012NTP AV)	
	XC7370022	DIAL SHEET (XL5500, XL5500SE, XL5500NTC AV)	
	XC7370035	DIAL SHEET (RS-15)	
8	XA5735022	DIAL SHEET (XL5130, RXL5130)	

No.	CODE.	NAME	REMARKS
9	XA4685021	BH KNOB SPACER	
	XA4685051	BH KNOB SPACER (PX100, PX100HC, PX100NTC, RPX100, PX110NTC)	
	XC7433021	BH KNOB SPACER (XL5050, XL5050NTC, XL5500, XL5500SE, XL5500NTC AV, RS15)	

(7) PATTERN SELECTION MECHANISM without BH CONNECTING LINK ASSY

XL5010, XL5010NTP, XL5011, XL5011AV,
XL5011NTC, XL5011NTP, XL5012, XL5012AV, XL5012NTP,
XL5012NTP AV, XL5050, XL5050NTC



XL5130, RXL5130, XL5500, XL5500SE,
XL5500NTC AV, RS15



PX100, PX100HC, PX100NTC,
PX110NTC, RPX100



(7) PATTERN SELECTION MECHANISM with BH CONNECTING LINK ASSY

No.	CODE.	NAME	REMARKS
1	XA5798121	PATTERN SELECTING UNIT ASSY (XL5300, XL5340, RXL5340)	
	XA6011121	PATTERN SELECTING UNIT ASSY (XL5030, XL5030NTP, XL5031, XL5031AV, XL5031NTP, XL5031NTC, XL5032, XL5032AV、XL5032NTP, XL5032NTP AV, XL5070, XL5070NTC)	
	XA6033121	PATTERN SELECTING UNIT ASSY (XL5020, XL5021, XL5021AV, XL5021AV, XL5021NTP, XL5021NTC, XL5020NTP, XL5022NTP, XL5022NTP AV, XL5060, XL5060NTC)	
	XA6034121	PATTERN SELECTING UNIT ASSY (XL5232, RXL5232)	
	XC7378021	PATTERN SELECTING UNIT ASSY (XL5600, XL5600NTC AV, RS25)	
	XC7391021	PATTERN SELECTING UNIT ASSY (XL5700, XL5700NTC AV, RS35)	
	XA9838021	PATTERN SELECTION UNIT ASSY (PX200, PX200HC, PX220NTC, PX200NTC)	
	XA9839021	PATTERN SELECTION UNIT ASSY (PX300, PX300HC, PX330NTC, PX300NTC)	
2	X57908021	TAPTITE, BIND S M4X10	
	X57908051	TAPTITE,BIND S M4X10 (XL5600, XL5600NTC AV, RS25)	
3	XA5736021	PATTERN SELECTION DIAL	
	XA6371021	PATTERN SELECTION DIAL (PX200, PX200HC, PX220NTC, PX300, PX300HC, PX330NTC)	
	XA6371022	PATTERN SELECTION DIAL (PX300NTC)	
	XA6371024	PATTERN SELECTION DIAL (PX200NTC)	
	XC7343021	PATTERN SELECTION DIAL (XL5060, XL5060NTC, XL5070, XL5070NTC XL5600, XL5600NTC AV, XL5700, XL5700NTC RS25, RS35)	
4	XA6372021	PATTERN DECORATION GEAR 1 (PX200, PX200HC, PX200NTC, PX220NTC, PX300, PX300HC, PX300NTC, PX330NTC)	
5	XA5734021	MANUAL DIAL (XL5232, RXL5232, XL5340, XL5300, RXL5340)	
	XC7339121	MANUAL DIAL (XL5600, XL5600NTC AV, XL5700, XL5700NTC AV, RS25, RS35)	

No.	CODE.	NAME	REMARKS
6	XA6373021	ZIGZAG DIAL (PX200, PX200HC, PX220NTC, PX300, PX300HC, PX330NTC)	
	XA6373022	ZIGZAG DIAL (PX300NTC)	
	XA6373024	ZIGZAG DIAL (PX200NTC)	
7	XA6003021	DIAL SHEET (XL5300)	
	XA6003023	DIAL SHEET (XL5030, XL5030NTP)	
	XA6003024	DIAL SHEET (XL5020, XL5020NTP)	
	XA6003031	DIAL SHEET (XL5021, XL5021AV, XL5021NTP, XL5021NTC)	
	XA6003032	DIAL SHEET (XL5031, XL5031AV, XL5031NTP, XL5031NTC)	
	XA6003035	DIAL SHEET (XL5232, RXL5232)	
	XA6003038	DIAL SHEET (XL5032, XL5032AV, XL5032NTP, XL5032NTP AV)	
	XA6003039	DIAL SHEET (XL5022AV, XL5022NTP, XL5022NTP AV)	
	XC7370024	DIAL SHEET (XL5600, XL5600NTC AV)	
	XC7370026	DIAL SHEET (XL5700, XL5700NTC AV)	
	XC7370037	DIAL SHEET (RS-25)	
	XC7370039	DIAL SHEET (RS-35)	
8	XA4025021	BH CONNECTING LINK ASSY	
9	060400416	SCREW, BIND M4X4	
10	048030346	RETAINING RING, E3	
11	XA5735022	DIAL SHEET (XL5232, RXL5232, XL5340, RXL5340)	
12	XA4685021	BH KNOB SPACER	
	XA4685051	BH KNOB SPACER (XL5340, RXL5340)	
	XC7433021	BH KNOB SPACER (XL5060, XL5060NTC, XL5070, XL5070NTC, XL5600, XL5600NTC AV, XL5700, XL5700NTC, RS25, RS35)	

(7) PATTERN SELECTION MECHANISM with BH CONNECTING LINK ASSY

PX200, PX200HC, PX200NTC, PX220NTC
PX300, PX300HC, PX300NTC, PX330NTC



XL5020, XL5020NTP, XL5021, XL5021AV, XL5021NTC, XL5021NTP, XL5022AV, XL5022NTP, XL5022NTP AV, XL5060, XL5060NTC, XL5030, XL5030NTP, XL5031, XL5031AV, XL5031NTC, XL5031NTP, XL5032, XL5032AV, XL5032NTP, XL5032NTP AV, XL5070, XL5070NTC



XL5232, RXL5232
XL5300, XL5340, RXL5340)



XL5600, XL5600NTC AV, RS25,
XL5700, XL5700NTC AV, RS35



(8) BOBBIN WINDER / THREAD GUIDE / LAMP MECHANISM

No.	CODE.	NAME	REMARKS
		BOBBIN WINDER MECHANISM	
1	XA3273121	BOBBIN WINDER HOLDER SUB ASSY	
	XC7347021	BOBBIN WINDER HOLDER SUB ASSY (XL5050, XL5050NTC, XL5060, XL5060NTC, XL5070, XL5070NTC, XL5500, XL5500SE, XL5500NTC AV, XL5600, XL5600NTC AV, XL5700, XL5700NTC AV, RS15. RS25, RS35)	
2	120448021	BOBBIN WINDER RUBBER BAND	
3	125928020	BOBBIN WINDER SHAFT SPRING	
4	X59939021	BOBBIN WINDER SPRING	
5	XA3133121	SS CHANGE HOLDER ASSY	
6	XA3136021	F DIAL SPRING	
7	062400416	SCREW, PAN M4X4	
8	X57913021	TAPTITE, BIND S M4X16	
		THREAD GUIDE MECHANISM	
9	XA5805021	THREAD GUARD ASSY	
	XC7349021	THREAD GUARD ASSY (XL5050, XL5050NTC, XL5060, XL5060NTC, XL5070, XL5070NTC, XL5500, XL5500SE, XL5500NTC AV, XL5600, XL5600NTC AV, XL5700, XL5700NTC AV, RS15, RS25, RS35)	
	XA6374021	THREAD GUIDE ASSY (PX Series)	
10	X57908021	TAPTITE, BIND S M4X10	
11	060400416	SCREW, BIND M 4X4	
		LAMP MECHANISM	
12	XC0492021	ASSY : SEWING LAMP E12C#16 (XL5130), (RXL5130, RXL5232: U.S.A.), (XL5232), (XL5340), (XL5500, 5600, 5700:CAN), (PX100, PX200, PX300: U.S.A., MEXICO)	
	XC7352021	ASSY : SEWING LAMP E12C#24 (XL5500, XL5600, XL5700: U.S.A.)	
	XA1064021	SEW-LIGHT ASSY	
	XA1064051	SEW-LIGHT ASSY (RXL5130, RXL5232: SINGAPORE), (RXL5340), (RPX100)	
13	X53061020	SEW-LIGHT BULB (XL5130), (RXL5130: U.S.A.), (XL5232), (RXL5232: U.S.A.), (XL5340), (XL5500, 5600, 5700: U.S.A., CAN) (PX100, PX200, PX300: U.S.A., MEXICO)	.
	205336020	SEW-LIGHT BULB L-4	
	205336050	SEW-LIGHT BULB L-4 (RXL5130, RXL5232: SINGAPORE), (RXL5340), (RPX100)	

No.	CODE.	NAME	REMARKS
14	X57984021	TAPTITE, BIND S M3X20 (XL5130), (RXL5130: U.S.A.), (XL5500: U.S.A., CAN), (XL5232), (RXL5232: U.S.A.), (XL5600: U.S.A., CAN), (XL5340), (XL5700: U.S.A., CAN), (PX100, PX200, PX300: U.S.A., MEXICO)	
15	XA1623021	TAPTITE, BIND S M3X10	
	XA1623051	TAPTITE, BIND S M3X10 (RXL5130, RXL5232: SINGAPORE), (RXL5340) (RPX100)	
16	XA4036021	LAMP HOLDER (XL5130), (RXL5130: U.S.A.), (XL5500: U.S.A., CAN), (XL5232), (RXL5232: U.S.A.), (XL5600: U.S.A., CAN), (XL5340), (XL5700: U.S.A., CAN), (PX100, PX200, PX300: U.S.A., MEXICO)	
17	060300616	SCREW, BIND M3X6 (XL5130), (RXL5130: U.S.A.), (XL5500: U.S.A., CAN), (XL5232), (RXL5232: U.S.A.), (XL5600: U.S.A., CAN), (XL5340), (XL5700: U.S.A., CAN), (PX100, PX200, PX300: U.S.A., MEXICO)	
18	X53169020	BAND	
	X53169050	BAND (XL5130, RXL5232, XL5232, RXL5130, RXL5340, RPX100)	
19	XA7678021	CORD CRAMP	
	XA7678051	CORD CRAMP (RXL5232: SINGAPORE), (RXL5340), (RPX100)	
20	X57908021	TAPTITE, BIND S M4X10	
21	XA8463021	CORD GUIDE	

(8) BOBBIN WINDER / THREAD GUIDE / LAMP MECHANISM



(9) MOTOR UNIT

No.	CODE.	NAME	REMARKS
1	XA1196021	T BELT B163XXL4.8	
2	XA3004021	BOLT.(S/P WASHER) M5X12	
	XA3004051	BOLT.(S/P WASHER) M5X12 (RXL5130), (RXL5232), (RXL5340), (XL5600: GER, U.K., FRA), (XL5600NTC AV) (RS25), (RPX100)	
3	XA8786021	3P SOCKET BODY	
4	XA8787021	3P SOCKET COVER	
5	052403006	SCREW, PAN (S/P WASHER) M4X30	
6	214808020	CONNECTOR:#3	
	214808050	CONNECTOR:#3 (RXL5130, RXL5232, RXL5340, RPX100)	
7	XA1073021	PW SWITCH ASSY	
	XA1070021	PW SWITCH ASSY (XL5130), (XL5232), (XL5340), (RXL5130, RXL5232: U.S.A.), (PX100, PX200, PX300: U.S.A., MEXICO) (XL5500, XL5600, XL5700: U.S.A., CAN)	
	XA1073051	PW SWITCH ASSY (RXL5130, RXL5232: SINGAPORE) (RXL5340), (RPX100)	
8	XA1071321	MOTOR : MM-BU1-9C (120V) (XL5130), (XL5500, XL5600, XL5700: CAN), (XL5232), (XL5340), (PX100, PX200, PX300: U.S.A., MEXICO)	
	XA1071351	MOTOR : MM-BU1-9C (120V) (RXL5130, RXL5232: U.S.A.)	
	XA1429121	MOTOR : MM-251-51 (220V) (XL5300), (PX100: ARG, CHILE, CHINA), (PX200: ARG, CHILE, CHINA, IRAQ), (PX300: ARG, CHILE, CHINA, IRAQ), (PX100HC, PX200HC, PX300HC: CHILE)	
	XA1430121	MOTOR : MM-251-52 (230V)	
	XA1430151	MOTOR : MM-251-52 (230V) (RXL5130, RXL5232: SINGAPORE), (RXL5340), (RPX100)	
	XA1431121	MOTOR : MM-251-53 (240V) (PX300: NEW ZEALAND)	
	XA2252121	MOTOR : MM-251-54 (220V) (XL5010, XL5020: KOREA), (PX100, PX200, PX300: KOREA)	040158
	XC7354021	MOTOR:HFA-07150 FDM (120V) (XL5500, XL5600, XL5700: U.S.A.)	
	XC7436021	MOTOR : NS-70 FDM230V (230V) (XL5050), (XL5050NTC), (XL5060), (XL5060NTC), (XL5070), (XL5070NTC), (XL5500, XL5600, XL5700: GER, U.K., FRA), (XL5500SE), (XL5500NTC AV), (XL5600NTC AV), (XL5700 NTC AV), (RS15), (RS25), (RS35)	
	XC7599021	MOTOR : NS-70 FDM220V (220V) (XL5500, XL5700: CHILE)	
9	XA1265120	MOTER T-PULLEY A	
10	XA1266120	MOTER T-PULLEY B	
	XC7355021	MOTOR T-PULLEY B (XL5050), (XL5050NTC), (XL5060), (XL5060NTC), (XL5070), (XL5070NTC), (XL5500, XL5700: U.S.A., CHILE, GER, U.K., FRA), (XL5500SE), (XL5500NTC AV), (XL5600: U.S.A., GER, U.K., FRA), (XL5600NTC AV), (XL5700NTC AV) (RS15), (RS25), (RS35)	
11	138598021	SOCKET PIN	
	138598051	SOCKET PIN (RXL5130, RXL5232, RXL5340, RPX100)	
12	XC2138020	SPACER (XL5130), (RXL5130, RXL5232: U.S.A.), (XL5232), (XL5340), (XL5500, XL5600, XL5700: U.S.A., CAN), (PX100, PX200, PX300: U.S.A., MEXICO)	
13	XC2139020	WASHER (XL5130), (RXL5130, RXL5232: U.S.A.), (XL5232), (XL5340), (XL5500, XL5600, XL5700: U.S.A., CAN), (PX100, PX200, PX300: U.S.A., MEXICO)	
14	XC2137120	MOTOR SUPPORTER (XL5130), (RXL5130, RXL5232: U.S.A.), (XL5232), (XL5340), (XL5500, XL5600, XL5700: U.S.A., CAN), (PX100, PX200, PX300: U.S.A., MEXICO)	
15	021400205	NUT, 2 M4	
16	X57908021	TAPTITE, BIND S M4X10 (XL5130), (RXL5130, RXL5232: U.S.A.), (XL5232), (XL5340), (XL5500, XL5600, XL5700: U.S.A., CAN), (PX100, PX200, PX300: U.S.A., MEXICO)	

(9) MOTOR UNIT



(9) MOTOR UNIT

No.	CODE.	NAME	REMARKS
17	028040242	WASHER, SPRING 2-4 (XL5130), (RXL5130, RXL5232: U.S.A.), (XL5232), (XL5340), (XL5500, XL5600, XL5700: U.S.A., CANADA), (PX100, PX200, PX300: U.S.A., MEXICO)	
18	102707023	WASHER (XL5130), (XL5232), (XL5340), (XL5500, XL5600, XL5700: U.S.A., CANADA), (PX100, PX200, PX300: U.S.A., MEXICO)	
	102707053	WASHER (RXL5130, RXL5232: U.S.A.)	
19	XA6400151	FOOT CONTROLLER : FC-307-51 (RXL5130, RXL5232: SINGAPORE), (RXL5340), (RPX100)	
	XA6412221	FOOT CONTROLLER : FC-307-58 (XL5010, XL5020, XL5030, PX100, PX200, PX300: IRELAND, U.K.), (XL5011), (XL5012AV), (XL5010NTP), (XL5011NTC), (XL5012NTP), (XL5012NTP AV), (XL5021), (XL5021AV), (XL5020NTP), (XL5021NTC), (XL5022NTP), (XL50222NTP AV), (XL5031), (XL5031AV), (XL5030NTP), (XL5031NTC), (XL5032NTP), (XL5032NTP AV), (PX100NTC), (PX110NTC), (PX200NTC), (PX220NTC), (PX300NTC), (PX330NTC)	050032
	XA6414121	FOOT CONTROLLER : FC-307-59 (PX300: NEW ZEALAND)	
	XA6422321	FOOT CONTROLLER : FC-307-63	050032
	XA6424121	FOOT CONTROLLER : FC-307-64 (XL5010, XL5020, PX100, PX200, PX300: KOREA)	
	XA6430121	FOOT CONTROLLER : FC-307-67 (PX100, PX200, PX300: CHINA)	
	XC0878121	FOOT CONTROLLER : FC-307-69 (PX100, PX200, PX300: ARGENTINE)	
	XC6659151	FOOT CONTROLLER : FC-317-21-LF (RXL5130, RXL5232: U.S.A.)	
	XC6666121	FOOT CONTROLLER : FC-317-27-LF (XL5130), (XL5232), (XL5340), (XL5500, XL5600, XL5700: CANADA), (PX100, PX200, PX300: U.S.A., MEXICO)	
	XC7359021	FOOT CONTROLLER:KD-1902 (XL5500, XL5600, XL5700: U.S.A.)	

No.	CODE.	NAME	REMARKS
	XC7438321	FOOT CONTROLLER:KD-2902 (XL5050: GER, FRA, ITA, SWI, RUS, SING) (XL5060: GER, FRA, ITA, RUS, SING) (XL5070: GER, FRA, SWI, RUS, SING) (XL5500, XL5700: CHILE, GER, FRA) (XL5500SE), (XL5600: GER, FRA), (RS15), (RS25), (RS35)	050032
	XC7456321	FOOT CONTROLLER:KD-2902UK (XL5050, XL5060, XL5070, XL5500, XL5600, XL5700: U.K.), (XL5050NTC), (XL5060NTC), (XL5070NTC), (XL5500NTC AV), (XL5600NTC AV), (XL5700NTC AV),	050032

(9) MOTOR UNIT



(10) ATTACHEMENTS / PACKING MATERIALS / PRINTED MATTERS

No.	CODE.	NAME	REMARKS
		ATTACHMENTS	
1	X55467021	SCREW DRIVER	
	X55467051	SCREW DRIVER (RXL5130, RXL5232, RXL5340, RPX100)	
2	X59370021	ZIPPER FOOT	
	X59370051	ZIPPER FOOT (RXL5130, RXL5232, RXL5340, RPX100)	
3	X59374021	STRAIGHT STITCH PRESSER FOOT	
	X59374051	STRAIGHT STITCH PRESSER FOOT (RXL5130, RPX100)	
4	X54243001	SEAM RIPPER (EXCEPT: XL5130, RXL5130, XL5232, XL5500: U.S.A., CAN, CHILE, RXL5232, XL5600: U.S.A., CAN, XL5340, RXL5340 XL5700: U.S.A., CAN, CHILE)	
5	X52800120	BOBBIN	
	X52800150	BOBBIN (RXL5130, RXL5232, RXL5340, RPX100)	
6	X55465021	OILER (XL5010, XL5010NTP, XL5011, XL5011AV, XL5011NTC, XL5011NTP, XL5012, XL5012AV, XL5012NTP, XL5012NTP AV, XL5020, XL5030, XL5020NTP, XL5021, XL5021AV, XL5021NTC, XL5021NTP, XL5022AV, XL5022NTP, XL5032, XL5022NTP AV, XL5030NTP, XL5031, PX100, XL5031AV, XL5031NTC, XL5031NTP, XL5032AV, XL5032NTP, XL5032NTP AV, PX100HC, PX100NTC, PX110NTC, RPX100, PX200, PX200HC, PX200NTC, PX220NTC, PX300, PX300HC, PX300NTC, PX330NTC)	
	X55465051	OILER (XL5050), (XL5050NTC), (XL5060), (XL5070), (XL5060NTC), (XL5070NTC), (XL5500SE), (XL5500, XL5600, XL5700: GER, U.K., FRA), (XL5600NTC AV), (XL5700NTC AV), (RS15), (RS25), (RS35)	
7	129583021	NEEDLE SET (3PCS)	
	129583001	NEEDLE SET (3PCS) (RXL5130, RXL5232, RXL5340, RPX100)	
8	X57521021	NEEDLE PACKAGE (1PCE)	
	X57521001	NEEDLE PACKAGE (1PCE) (RXL5130), (RXL5232), (RXL5340), (RPX100), (XL5600: GER, U.K., FRA), (XL5600NTC AV), (RS25)	

No.	CODE.	NAME	REMARKS
9	X58358021	Z NEEDLE ASSY (XL5012AV), (XL5022AV), (XL5021AV), (XL5022NTP AV), (XL5032AV), (XL5031AV), (XL5032NTP AV), (XL5130, XL5232: CANADA)	
	X58358051	Z NEEDLE ASSY (XL5500, XL5600: CANADA), (XL5600NTC AV), (XL5700NTC AV)	
10	130920021	EXTRA SPOOL PIN	
	130920051	EXTRA SPOOL PIN (RXL5130, RXL5232, RXL5340, RPX100)	
11	XA3442121	FEED DOG COVER (XL5010), (XL5010NTP), (XL5011), (XL5011AV), (XL5011NTC), (XL5011NTP), (XL5012), (XL5012AV), (XL5012NTP), (XL5012NTP AV), (XL5020), (XL5020NTP), (XL5021), (XL5021AV), (XL5021NTC), (XL5021NTP), (XL5022AV), (XL5022NTP), (XL5022NTP AV), (XL5050), (XL5050NTC AV), (XL5060), (XL5060NTC AV), (XL5030), (XL5030NTP), (XL5031), (XL5031AV), (XL5031NTC), (XL5031NTP), (XL5032), (XL5032AV), (XL5032NTP), (XL5032NTP AV), (XL5070), (XL5070NTP AV) (XL5130), (XL5500, XL5700: U.S.A., CAN, CHILE), (XL5600: U.S.A., CAN), (XL5340), (XL5300), (XL5232)	
	XA3442151	FEED DOG COVER (RXL5130, RXL5232, RXL5340)	
12	XA4911121	BH PRESSER FOOT ASSY (XL5020), (XL5020NTP), (XL5021), (XL5021AV), (XL5021NTC), (XL5021NTP), (XL 5022AV), (XL5022NTP), (XL5022NTP AV), (XL5060) (XL5060NTC), (XL5030), (XL5030NTP), (XL5031), (XL5031AV), (XL5031NTC), (XL5032), (XL5031NTP), (XL5032AV), (XL5032NTP), (XL5032NTP AV), (XL5070), (XL5070NTC), (XL5232), (XL5600), (XL5300), (XL5600NTC AV), (RS25), (XL5340), (RXL5340), (XL5700: U.S.A., CAN, CHILE), (PX200), (PX200HC), (PX200NTC), (PX220NTC), (PX300), (PX300HC), (PX300NTC), (PX330NTC)	
	XA4911151	BH PRESSER FOOT ASSY (RXL5232), (RXL5340), (RS35), (XL5700: GER, U.K, FRA), (XL5700NTC AV)	

(10) ATTACHEMENTS / PACKING MATERIALS / PRINTED MATTERS



(10) ATTACHEMENTS / PACKING MATERIALS / PRINTED MATTERS

No.	CODE.	NAME	REMARKS
13	X59369321	BUTTON HOLE FOOT ASSY (XL5010), (XL5010NTP), (XL5011), (XL5011AV), (XL5011NTC), (XL5011NTP), (XL5012), (XL5012AV), (XL5012NTP), (XL5012NTP AV), (XL5050), (XL5050NTC), (XL5130), (XL5500), (XL5500NTC AV), (XL5500SE), (RS15), (PX100), (PX100HC), (PX100NTC), (PX110NTC), (PX150)	
	X59369351	BUTTON HOLE FOOT ASSY (RPX100, RXL5130)	
14	X59375121	BUTTON SEWING FOOT	
	X59375151	BUTTON SEWING FOOT (RXL5130, RXL5232, RXL5340, RPX100)	
	180083001	DARNING FOOT (PX100HC, PX200HC, PX300HC: CHILE)	
15	XA3805051	1/4' QUILTING FOOT (XL5232), (RXL5232), (XL5340), (RXL5340),	
	XA3805021	1/4' QUILTING FOOT (XL5700: U.S.A., CAN, CHILE)	
16	122329001	NARROW HEMMER (XL5130, XL5232: CANADA)	
17	X59371021	NARROW HEMMER FOOT (XL5130: U.S.A.), (XL5600: U.S.A., CAN), (XL5500, XL5700: USA, CAN, CHILE), (XL5340)	
18	X53189001	PRESSER FOOT ASSEMBLY (XL5232, XL5500, XL5600: CANADA)	
19	XA7875001	PEARL SEQUENCE FOOT (XL5130, XL5500, XL5232, XL5600: CANADA)	
20	X59372021	BLIND STITCH FOOT (XL5130: U.S.A.), (XL5340), (RS15), (RS25), (RS35), (XL5500), (XL5500NTC AV), (XL5500SE), (XL5600), (XL5600NTC AV), (XL5700), (XL5700NTC AV), (PX100), (PX100HC), (PX100NTC), (PX110NTC), (PX150)	
	X59372051	BLIND STITCH FOOT (RPX100)	
21	125905001	PIN TUCK PRESSER FOOT (XL5340), (XL5700: U.S.A., CAN, CHILE)	
22	XC4487021	ACCESSORY BAG	
	XC4487051	ACCESSORY BAG (RXL5130, RXL5232, RXL5340, RPX100)	

No.	CODE.	NAME	REMARKS
23	XC1807121	SCISSORS (XL5012AV), (XL5011AV), (XL5012NTP AV), (XL5022AV), (XL5021AV), (XL5022NTP AV), (XL5032AV), (XL5031AV), (XL5032NTP AV), (XL5130, XL5500, XL5232, XL5600: CANADA), (XL5500NTC AV), (XL5600NTC AV), (XL5700NTC AV)	
24	XA5772021	MEASURE (XL5012AV), (XL5011AV), (XL5012NTP AV), (XL5022AV), (XL5021AV), (XL5022NTP AV), (XL5032AV), (XL5031AV), (XL5032NTP AV), (XL5130, XL5500, XL5232, XL5600: CANADA), (XL5500NTC AV), (XL5600NTC AV), (XL5700NTC AV)	040158
25	XA8547021	PIN CUSHIN (XL5012AV), (XL5022AV), (XL5032AV), (XL5031AV), (XL5032NTP AV), (XL5130, XL5500, XL5232, XL5600: CANADA), (XL5700NTC AV)	
26	264030021	BAG, 165X250 (XL5012AV), (XL5022AV), (XL5032AV), (XL5031AV), (XL5032NTP AV), (XL5130, XL5500, XL5232, XL5600: CANADA), (XL5700NTC AV)	
	X53984027	DUST COVER ASSY	
	X53984057	DUST COVER ASSY (RPX100)	
	XC1103021	DUST COVER ASSEMBLY (XL5011NTC, XL5021NTC, XL5031NTC, PX100NTC, PX110NTC, PX200NTC, PX220NTC, PX300NTC, PX330NTC)	
	XC1103051	DUST COVER ASSEMBLY (XL5050NTC, XL5060NTC, XL5070NTC, XL5500NTC AV, XL5600NTC AV, XL5700NTC AV)	
		PACKING MATERIALS	
27	X61361056	CARTON (XL5010)	
	X61361060	CARTON (XL5010: RUSSIA, SINGAPORE)	
	X61361070	CARTON (XL5010NTP)	
	X61361057	CARTON (XL5011)	
	X61361058	CARTON (XL5011AV)	
	X61361088	CARTON (XL5011NTP)	
	X61361071	CARTON (XL5011NTC)	
	X61361069	CARTON (XL5012)	

(10) ATTACHEMENTS / PACKING MATERIALS / PRINTED MATTERS



(10) ATTACHEMENTS / PACKING MATERIALS / PRINTED MATTERS

No.	CODE.	NAME	REMARKS
27	X61361086	CARTON (XL5012: SINGAPORE)	
	X61361059	CARTON (XL5012AV)	
	X61361078	CARTON (XL5012NTP)	
	XC7593030	CARTON (XL5012NTP AV)	
	X61361061	CARTON (XL5020)	
	X61361064	CARTON (XL5020: RUSSIA, SINGAPORE)	
	X61578029	CARTON (XL5020: KOREA)	
	X61361072	CARTON (XL5020NTP)	
	X61361062	CARTON (XL5021)	
	X61361063	CARTON (XL5021AV)	
	X61361073	CARTON (XL5021NTC)	
	X61361089	CARTON (XL5021NTP)	
	X61361076	CARTON (XL5022AV)	
	X61361079	CARTON (XL5022NTP)	
	XC7593031	CARTON (XL5022NTP AV)	
	X61361065	CARTON (XL5030)	
	X61361068	CARTON (XL5030: RUSSIA, SINGAPORE)	
	X61361074	CARTON (XL5030NTP)	
	X61361066	CARTON (XL5031)	
	X61361067	CARTON (XL5031AV)	
	X61361075	CARTON (XL5031NTC)	
	X61361090	CARTON (XL5031NTP)	
	X61361087	CARTON (XL5032)	
	X61361077	CARTON (XL5032AV)	
	X61361080	CARTON (XL5032NTP)	
	XC7593032	CARTON (XL5032NTP AV)	
	X61383028	CARTON (XL5130)	
	X61383024	CARTON (XL5130: CANADA)	
	X61383056	CARTON (RXL5130: U.S.A.)	
	XC5393052	CARTON (RXL5130: SINGAPORE)	
	X61383025	CARTON (XL5232)	
	X61383057	CARTON (RXL5232: U.S.A.)	
	XC5393051	CARTON (RXL5232: SINGAPORE)	
	X61383029	CARTON (XL5340)	
	X61361021	CARTON (XL5300)	
	XC5393053	CARTON (RXL5340)	
	X61361097	CARTON (XL5050)	
	XC7593027	CARTON (XL5050NTC)	
	X61361098	CARTON (XL5060)	
	XC7593028	CARTON (XL5060NTC)	
	X61361099	CARTON (XL5070)	
	XC7593029	CARTON (XL5070NTC)	
	X61383030	CARTON (XL5500: U.S.A., CANADA)	
	XC7593021	CARTON (XL5500: GER, U.K, FRA)	

No.	CODE.	NAME	REMARKS
	X61383034	CARTON (XL5500: CHILE)	
	XC7593034	CARTON (XL5500SE)	
	XC7593035	CARTON (RS-15)	
	X61383031	CARTON (XL5600: U.S.A., CANADA)	
	XC7593022	CARTON (XL5600: GER, U.K, FRA)	
	XC7593025	CARTON (XL5600NTC AV)	
	XC7593036	CARTON (RS-25)	
	X61383032	CARTON (XL5700: U.S.A., CANADA)	
	X61383033	CARTON (XL5700: CHILE)	
	XC7593026	CARTON (XL5700NTC AV)	
	XC7593037	CARTON (RS-35)	
	X61361029	CARTON (PX100: U.S.A.)	
	X61361046	CARTON (PX100: ARG, CHILE, MEX, SPA, ITA)	
	X61361034	CARTON (PX100: CHINA)	
	X61578026	CARTON (PX100: KOREA)	
	X61578023	CARTON (PX100HC)	
	X61361083	CARTON (PX100NTC)	
	X61361096	CARTON (PX110NTC)	
	X61361095	CARTON (PX150)	
	X61361047	CARTON (PX100: Other country)	
	X61361028	CARTON (PX200: U.S.A.)	
	X61361048	CARTON (PX200: ARG, CHILE, MEX, SPA, POR, ITA)	
	X61361085	CARTON (PX200: SINGAPORE)	
	X61361035	CARTON (PX200: CHINA)	
	X61578022	CARTON (PX200HC, PX200: KOREA)	
	X61578027	CARTON (PX200:IRAQ)	
	X61361082	CARTON (PX200NTC)	
	XC7593033	CARTON (PX220NTC)	
	X61361049	CARTON (PX200: Other country)	
	X61361027	CARTON (PX300: U.S.A.)	
	X61361054	CARTON (PX300: ARG, CHILE, MEX, SPA, ITA)	
	X61578022	CARTON (PX200HC, PX200: KOREA)	
	X61361084	CARTON (PX300: SINGAPORE)	
	X61361036	CARTON (PX300: CHINA)	
	X61578028	CARTON (PX300:IRAQ)	
	X61578021	CARTON (PX300HC)	
	X61361081	CARTON (PX300NTC)	
	X61361094	CARTON (PX330NTC)	
	X61361055	CARTON (PX300: Other country)	

(10) ATTACHEMENTS / PACKING MATERIALS / PRINTED MATTERS



(10) ATTACHEMENTS / PACKING MATERIALS / PRINTED MATTERS

No.	CODE.	NAME	REMARKS
28	X61363021	457 POLYSTYRENE ASSY (XL50*0, XL5130, XL5232, XL5300, XL5340), (PX100, PX200, PX300)	
	X61363022	457 POLYSTYRENE ASSY (XL5010: KOREA), (PX300: KOREA)	
	X61363051	457 POLYSTYRENE ASSY (RXL5130, RXL5232, RXL5340, RPX100)	
	XC7366021	POLYSTYRENE FOAM PAD ASSY,458 (XL5050, 5060, 5070, 5500, 5600, 5700)	
	X61570021	467 CASE POLY-STYRENE ASSY (PX100HC, PX200HC, PX300HC), (PX200, PX300: IRAQ)	
	X61570022	467 CASE POLY-STYRENE ASSY (XL5020, PX100, PX200: KOREA)	
	X60853020	OVER CASE POLYSTYRENE (PX100HC, PX200HC, PX300HC: SPAIN), (PX200, PX300: IRAQ)	
	X60853021	OVER CASE POLYSTYRENE (PX100, PX200: KOREA)	
	264030021	BAG, 165X250 (XL5232, XL5300, XL5340), (XL5500, XL5600, XL5700: CANADA)	
	264030051	BAG, 165X250 (RXL5130, RXL5232, RXL5340, RPX100)	
	160670021	BAG, 150X350	
	160670051	BAG, 150X350 (RXL5130, RXL5232, RXL5340, RPX100)	
	X60439151	BAG, 630X630T (RXL5130, RXL5232, RXL5340, RPX100)	
	X60439121	BAG, 630X630T	
	X57847021	PLUG LABEL	
	X57325021	LABEL	
	X60352020	ACCESSORY TABLE PRESSER D	
	X60726020	FOOT CONTROLLER BOX	
	X61181021	STYLOFOAM	
	LA6041001	SECURITY TAG	
	XC7193021	STICKER	
	XC7680021	STICKER (XL5500: CANADA)	
PRINTED MATTERS			
	194447011	INSTRUCTION BOOK (IRE, U.K., SPA, POR, ITA, SWI, SIN)	
	194447012	INSTRUCTION BOOK (GER, BEL, FRA, HOL, SWI)	

No.	CODE.	NAME	REMARKS
	194447013	INSTRUCTION BOOK (PX*: FIN, DEN, SWE)	
	194447014	INSTRUCTION BOOK (AUSTRIA, RUSSIA), (XL5012: SIN)	
	194457012	INSTRUCTION BOOK (PX*: GER, BEL, FRA, HOL, SWI)	
	194457013	INSTRUCTION BOOK (PX*: FIN, DEN, SWE)	
	194457014	INSTRUCTION BOOK (PX*: AUSTRIA)	
	194457015	INSTRUCTION BOOK (PX*:ITA, SWI, CHINA)	
	194457017	INSTRUCTION BOOK (XL5130, RXL5130, XL5232, RXL5232, XL5340, RXL5340)	
	194457111	INSTRUCTION BOOK (XL5300, PX Other)	
	XC1672001	INSTRUCTION BOOK (PX200, 300: IRAQ)	
	XC5306021	INSTRUCTION BOOK (PX330NTC)	
	XC7094051	INSTRUCTION BOOK (RXL5130, RXL5232, RXL5340)	
	XC7132021	INSTRUCTION BOOK (PX110NTC, PX220NTC, PX330NTC)	
	XC6752021	INSTRUCTION BOOK (XL5050, XL5060, XL5070: U.K., RUS, SIN), (XL5050NTC), (XL5060NTC), (XL5070NTC)	
	XC6758021	INSTRUCTION BOOK (XL5050, XL5060, XL5070: FRA, SWI)	
	XC6885021	INSTRUCTION BOOK (XL5500, XL5600, XL5700: CAN, FRA)	
	XC6884021	INSTRUCTION BOOK (XL5500, XL5500SE, XL5600, XL5700: GER)	
	XC6886021	INSTRUCTION BOOK (XL5500, XL5600, XL5700: FRA)	
	XC7137021	INSTRUCTION BOOK (XL5050, XL5060, XL5070: FRA)	
	XC7144021	INSTRUCTION BOOK (XL5050, XL5060, XL5070: ITA, SWI)	
	XC7439021	INSTRUCTION BOOK (XL5050, XL5060, XL5070: GER, SWI)	
	XC7363021	INSTRUCTION BOOK (XL5500, XL5600, XL5700: U.S.A., CAN, U.K.) (XL5500NTC AV, 5600NTC AV, 5700NTC AV)	
	XC7364021	INSTRUCTION BOOK (XL5500, XL5600, XL5700: U.S.A, CHILE)	
	XC8509021	INSTRUCTION BOOK (RS15, RS25, RS35)	

(10) ATTACHEMENTS / PACKING MATERIALS / PRINTED MATTERS



(10) ATTACHEMENTS / PACKING MATERIALS / PRINTED MATTERS

No.	CODE.	NAME	REMARKS
	130800021	BAG, 220X310	
	130800051	BAG, 220X310 (RXL5130,RXL5232,RXL5340)	
	UH385100	WARRANTY CARD EUR	
	XC6402021	WARRANTY CARD (U.K.)	
	XC0380021	WARRANTY CARD (XL5130), (XL5232), (XL5340), (XL5500, 5600, XL5700: U.S.A.)	
	XC0435021	WARRANTY CARD (PX100, PX200, PX300: U.S.A.)	
	XC1153021	WARRANTY CARD (PX100, PX200, PX300: ARG)	
	XA6351121	WARRANTY CARD (POR, ITA)	
	XA8411121	WARRANTY CARD (PX100, PX200, PX300: CHINA)	
	XC9286021	CONTACT SHEET (XL5130, XL5232, XL5340, XL5500, XL5600, XL5700: CANADA)	040204
	181401165	INSERTION WARRANTY COUPON (XL5130, XL5232, XL5340, XL5500, XL5600, XL5700: CANADA)	DEL 040204
	181401172	INSERTION WARRANTY COUPON (XL5130, XL5232, XL5340, XL5500, XL5600, XL5700: CANADA)	
	181401230	INSERTION WARRANTY COUPON (XL5130, XL5232, XL5340, XL5500, XL5600, XL5700: CANADA)	
	XA7201021	USER'S MANUAL (XL5130: U.S.A., XL5340, XL5500, XL5500SE, XL5500NTC AV, XL5600, XL5600NTC AV, XL5700, XL5700NTC AV, RS15, RS25, RS35)	
	XC2067021	USER'S MANUAL (XL5232, XL5340, XL5600: CANADA), (XL5700: U.S.A, CANADA, CHILE)	
	XC2067051	USER'S MANUAL (RXL5232, RXL5340)	
	XC1885021	MANUAL (XL5130, XL5500, XL5232, XL5600, XL5340, XL5700: U.S.A, CANADA, CHILE)	
	XA7651021	MANUAL (XL5130, XL5232, XL5500, XL5600: CANADA)	
	XA7876021	MANUAL (XL5130, XL5232, XL5500, XL5600: CANADA)	
	XA9089021	MANUAL (XL5340, XL5700: U.S.A., CAN, CHILE)	

No.	CODE.	NAME	REMARKS
	XC6860021	MANUAL (XL5050), (XL5050NTC), (XL5060), (XL5060NTC), (XL5070), (XL5070NTC), (XL5500: GER, FRA), (XL5500SE), (XL5600: Except for U.S.A. CANADA), (XL5500NTC AV), (XL5600NTC AV), (XL5700: GER, U.K, FRA), (XL5700NTC AV), (RS15, RS25, RS35)	
	XC0021021	OPERATION MANUAL (FINLAND)	
	XC4028121	QUICK START GUIDE (XL5011AV, XL5011NTC, XL5012NTP, XL5012NTP AV, XL5020NTC, XL5021NTC, XL5022NTP, XL5022NTP AV, XL5031NTC, XL5032NTP, XL5032NTP AV)	
	XC8324021	QUICK START GUIDE (XL5050NTC, XL5060NTC, XL5070NTC, XL5500NTC AV, XL5600NTC AV, XL5700NTC AV)	
	XC5407321	QUICK START GUIDE (PX100NTC, PX110NTC, PX200NTC, PX220NTC, PX300NTC, PX330NTC)	
	XC6911021	ACCINFO SHEET (XL5500, XL5600, XL5700: U.S.A.)	
	XD0254021	EEU WARRANTY CARD (XL5500, XL5600, XL5700 : EAST EUROPE)	050012

(10) ATTACHEMENTS / PACKING MATERIALS / PRINTED MATTERS



XL Series
PX Series
07E04HF885443-448/
453-458/
463/465/467